


Nice



Linking the TTX4 to a Motor

A remote handset must already be paired with the motor

1. Connect your push button switch as shown on the left hand side
2. Press and hold the stop button connected to the TTX4 for 8 seconds
3. Press the stop button on the paired remote 3 times
4. Press the stop button on the TTX4 1 time
5. The blind should move 3 times to confirm the TTX4 has been paired.

NOTE – If the blind moves 6 times the memory is full or locked and the TTX4 will not be paired.

TTX4 Wiring

CONTROL:

- 1 = Up
- 2 = Stop
- 3 = Down
- 4 = Stop (Not needed with most installations)
- 5 = Common

UNIT POWER:

- 6 = Live
- 7 = Neutral